



### 1 - TILT LOCK / UNLOCK LEVER

#### To lock tilt recline

Pull button forwards

—

#### To unlock tilt recline

Tirare il pulsante indietro



### 2 - HEIGHT ADJUSTMENT LEVER

#### To raise

With the right hand, pull lever up while taking your weight off chair

—

#### To lower

With the right hand, pull lever up while seated

#### PRODUCT NAME

**Armonico Tilt  
70 x 90 mm**

#### TYPE

**Tilt mechanism**

—

**Tilt mechanism  
with lock**

#### FEATURES \*

**Height adjustment**

—

**Tilt lock**

[\*] THE FEATURES MAY DIFFER  
ACCORDING TO THE TYPE OF  
SELECTED PRODUCT