



1 - HEIGHT ADJUSTMENT LEVER

To raise

With the right hand, pull lever up while taking your weight off chair

—

To lower

With the right hand, pull lever up while seated



1 - TILT LOCK / UNLOCK LEVER

To lock tilt recline

With the right hand, pull lever backwards

—

To unlock tilt recline

With the right hand, pull lever forwards

PRODUCT NAME

Epsilon

TYPE

Weight activated mechanism

FEATURES

Height adjustment

—

Tilt lock