



1 - HEIGHT ADJUSTMENT LEVER

To raise

With the right hand, pull lever up while taking your weight off chair

—

To lower

With the right hand, pull lever up while seated



1 - TILT LOCK / UNLOCK LEVER

To lock tilt recline

With the right hand, pull handle outwards

—

To unlock tilt recline

With the right hand, push handle inward



2 - TENSION ADJUSTMENT KNOB

To increase

Rotate knob clockwise

—

To decrease

Rotate knob counterclockwise

PRODUCT NAME

MPD38 Steel plate

TYPE

Tilt mechanism

FEATURES

Height adjustment

—

Comfort adjustment

—

Tilt lock