



POLISHED ALUMINIUM COMPONENTS

For cleaning

Use soft cloth and glass cleaner. To polish, apply aluminium polishing paste wax following the instructions on the label.

For disinfection

The use of **ethanol** is recommended, while the use of **sodium hypochlorite**, **hydrogen peroxide** and **benzalkonium chloride** is not recommended. *



PAINTED ALUMINIUM COMPONENTS

For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners

For disinfection

The use of **sodium hypochlorite** (0.1% - 0.5% sol.) is recommended, while the use of **hydrogen peroxide** is not recommended. **Denatured alcohol** and **ethanol** may generate some slight aesthetic changes. *



POLYPROPYLENE PLASTIC COMPONENTS

For cleaning

Use soft cloth and non-abrasive neutral detergent. Do not use alcohol, solvent-based, acid or abrasive cleaners

For disinfection

Denatured alcohol, **sodium hypochlorite** (0.1% - 0.5% sol.), **ethanol** (70% sol.), **hydrogen peroxide** (0.5% sol.) and **benzalkonium chloride** can be used.*

PRODUCT NAME

Armonico
70 x 90 mm seat connection

TYPE

Fixed support
—
Tilt mechanism

MATERIALS

Polished aluminium
—
Painted aluminium
—
Polypropylene plastic

* Analysis of the effects resulting from the application of chemicals on product surfaces, performed by an accredited laboratory.

Before disinfecting the entire surface of any component, it is advisable to proceed with tests on a small part of the product.